
begin
101
display default icons
102
phone disconnected from network?
N
Y
103
send a sleep signal to control chip for entering into a power saving mode
106
send a wakeup signal to control chip for returning to normal
104
phone disconnected from network?
N
Y
105
key pressed?
Y
N

FIG. 1